
# USER'S MANUAL / 36" WONDER WOMAN™

# TRAMPOLINE

Model: 16800993360





# A DANGER

DO NOT attempt somersaults or flips. Paralysis or death can result if you land on your head or neck!

No more than one person on the trampoline at a time. Multiple users increase the risk of injury.

Use trampoline only with mature, knowledgeable supervision.

# 

These instructions are important to minimize chances of injury. Please read each of them thoroughly before you assemble and use this trampoline. Retain this manual for future reference.

Maximum weight of the user shall NOT exceed 220lbs/100kg for this product.



DYACO CANADA INC. 5955 Don Murie St.

Niagara Falls, ON L2G 0A9

WONDER WOMAN<sup>™</sup> and all related characters and elements © & <sup>™</sup> DC Comics. WB SHIELD: © & <sup>™</sup> WBEI. (s18)







### INTRODUCTION

Thank you for purchasing this product! This trampoline was designed and manufactured with quality materials and craftsmanship, providing fun and exercise in the enjoyment of your home.

It is very important that the owners and users of this trampoline have adequate knowledge of techniques and rules for proper use. In particular, children must be supervised at all times by a knowledgeable and mature adult while using the trampoline. Take precautions to prevent access to the trampoline by children when there is no adult supervision. Also restrict access to any unauthorized users without your consent.

Carefully read and understand all of the instructions and warnings in the User Manual before assembling and using this product. It is the responsibility of the owner of this trampoline to ensure that all users of this product are fully informed on the proper use and the inherent risks of jumping on a trampoline. Failure to do so can result in serious injury or death. In particular, under no circumstances should you attempt or allow flips, somersaults or any similar conduct. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat. Also, do not allow more than one person on the trampoline under any circumstances. Use by more than one person at the same time increases the chance of injury.

Please also ensure proper placement of this product to avoid injuries. It is essential that the intended site for this trampoline is completely flat and level. If the ground is uneven, this could cause movement in the frame and stress on the joined sections of the frame that could damage the trampoline and/or can cause serious injury. Do not position this trampoline on hard surface such as concrete, tarmac or paving.

This product is designed for indoor and outdoor use. The product must not be used in windy conditions as wind can cause unexpected movement of the product. Wind can cause the trampoline to be lifted off the ground and become airborne. This can present a danger to individuals and to property. Store away in a safe place when it is not being used.

Only genuine replacement parts sold through our authorized agents are recommended. Replacement parts from other sources may not have been designed, tested or manufactured to standards. Because of this, we cannot guarantee the performance and safety of the product when non-genuine replacement parts are used. The use of non-genuine replacement parts may affect any warranty claim on the product, as allowed by the law in your jurisdiction.

Dyaco Canada warrants its products against defects in material and workmanship. Please refer to our warranty policy at the back of this manual for details.

DO NOT RETURN PRODUCT TO THE STORE. FOR CUSTOMER SERVICE OR REPLACEMENT PARTS, PLEASE CALL 1-888-707-1880 or <u>customerservice@dyaco.ca</u>.



- > Use trampoline only with mature, knowledgeable adult supervision.
- Do not attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat.
- Do not allow more than one person on the trampoline. Use by more than one person at the same time increases the chance of injury.

Before you start to assemble	1
Introduction	
Table of contents	3
Warnings	4
Trampoline Parts List	9
Assembly	10
Care and Maintenance	
Product Warranty	16



Carefully read and understand all of the instructions and safety warnings in this manual before assembling and using this product. It is the responsibility of the owner of this trampoline to ensure that all users of this product are fully informed on the proper safe use and the inherent risks of jumping on a trampoline. Failure to do so can result in serious injury or death.

### Needed two adult to assembled.

### Before you start to assemble...

- Check the package and make sure you have all of the parts listed in the Parts List section of this user manual. IF ANY PARTS ARE MISSING, please call the Customer Service toll-free number listed on the cover page for assistance.
- Do not install or use the product if any parts are missing or damaged. Store in a safe place until ready to install.
- Make sure that you have plenty of space and a clean dry area suitable for the assembly of this trampoline. IT IS ESSENTIAL THAT THE INTENDED SITE FOR THIS TRAMPOLINE IS COMPLETELY FLAT AND LEVEL. If the ground is uneven, this could cause movement in the frame and stress on the joined sections of the frame that could damage the trampoline and/or can cause serious injury.
- Never modify the construction or the design of the product. Do not use any unauthorized parts with this trampoline.
- This pack may contain small parts and is not suitable for children under three (3) years of age to be nearby during assembly.
- > **IMPORTANT:** Save this manual for future reference.

### Before using the product...

- Use of this trampoline requires constant adult supervision. Use the trampoline only with mature and knowledgeable ADULT supervision.
- > This product is intended for individual used by persons betweenages 3 to 10.
- There must be no more than one person at a time on the trampoline.
- Maximum weight of the user shall NOT exceed 220lbs/100kg for this product.
- This product is for personal use only. DO NOT use in any commercial, rental, professional or stunt performance setting.



- > Use trampoline only with mature, knowledgeable adult supervision.
- Do not attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat.
- Do not allow more than one person on the trampoline. Use by more than one person at the same time increases the chance of injury.

### Important Warnings



Carefully read these warnings before using this product. Failure to follow these safety instructions can result in serious injury or death.

# **A** DANGER

- Only one user at any one time! Multiple users can cause loss of control, collision or falls on the trampoline. This could result in serious injury to legs, arms, back, neck or head.
- Do not use the trampoline when under the influence of alcohol, drugs or medication, which may impair the jumper's judgement.
- > Always consult your physician before performing any kind of physical activity.
- > Do not use the trampoline if you have high blood pressure.
- > Do not use the trampoline if you have a medical history of neck or back injuries or mental or physical conditions that could cause injury.
- Do not use if the user has any broken bones (casts) or has recently been in the hospital for extensive treatments (operations, severe wounds, stitches, back injury or concussion).
- > Do not use without the consent of your physician, if pregnant.
- > Do not use if the user or the trampoline surface is wet. These conditions can cause the user to lose control and fall resulting in serious injury.



Customer Service 1-888-707-1880

- > Use trampoline only with mature, knowledgeable adult supervision.
- Do not attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat.
- Do not allow more than one person on the trampoline. Use by more than one person at the same time increases the chance of injury.



Carefully read these warnings before using this product. Failure to follow these safety instructions can result in serious injury or death.

## **WARNING**

### **Proper Play Conditions:**

- Always use the product in a well-lit area. Do not use without lighting during dawn, dusk or in complete darkness!
- The trampoline must be placed on a surface that is COMPLETELY FLAT AND LEVEL. If the ground is uneven, this could cause movement in the frame and could cause stress on the joined sections of the frame that could damage the trampoline and/or can cause serious injury.
- DO NOT install or position this trampoline on a hard surface such as concrete, tarmac or paving. Suitable surfaces are grass, sand or a play area covered with an appropriate depth of play bark material.
- Maintain clear space on all sides of the product. Make sure that there are no hazardous objects above, below or near the trampoline. Such objects include walls, fences, tree limbs/trunks, electrical power wiring, rocks, sprinkler heads or other recreational objects (i.e. swing sets, swimming pools). Children can be seriously injured colliding into such obstacles.
- The product must not be used in windy conditions as wind can cause unexpected movement of the product. Wind can cause the trampoline to be lifted off the ground and become airborne. This can present a danger to individuals and to property. Winds can be especially strong in open areas, foothills, mountains, locations subject to hurricanes and tornadoes, areas between homes that create wind tunnels and anywhere else where local weather conditions can create high winds. Damage from the wind or other severe weather is not covered by the manufacturer's warranty. Because the manufacturer warranty does not cover wind or weather-related damage and damage can be caused to your property or the property of others by a windblown trampoline, it is strongly advised that you provide site specific anchoring through a licensed local contractor.



- > Use trampoline only with mature, knowledgeable adult supervision.
- Do not attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat.
- > Do not allow more than one person on the trampoline. Use by more than one person at the same time increases the chance of injury.



Carefully read these warnings before using this product. Failure to follow these safety instructions can result in serious injury or death.

## **WARNING**

### Appropriate Use Conditions:

- Children must always be supervised while they are playing on the trampoline and must be instructed not to use the trampoline in an inappropriate or hazardous manner. Take precautions to prevent access to the trampoline by children when there is no adult supervision.
- > Restrict access to the trampoline by any unauthorized users without your consent.
- Trampolines are rebounding devices, which propel the user to unaccustomed heights, and into a variety of body movements. Rebounding off of the trampoline, striking the frame or springs, or improperly landing on the trampoline mat may cause serious injury.
- Always start and maintain your jump at the center of the trampoline mat in order to reduce the risk of landing on the frame or springs or falling off the trampoline.
- Avoid bouncing too high. Stay low until you can control your bounce and land consistently in the middle of the trampoline mat.
- Ensure the trampoline frame and springs are fully covered by the frame pad to avoid any direct contact with metal parts.
- Do not stand or jump on the springs while using the trampoline. The springs are not designed to support such stress and weight. This can result in serious injuries and/or product damage. If you see any signs of stretched or damaged springs, do not use the trampoline until replacement springs are properly installed. Please contact our customer service representatives to order original replacement parts.
- Jumping off the trampoline to the ground or any other surface may result in injury. Smaller children may need assistance getting up onto or down from the trampoline. Mounting and dismounting properly should be followed as a strict rule. Users should climb onto the trampoline by placing their hands on the frame and stepping or rolling up onto the frame, across the springs and onto the mat. Do not step directly on the frame pad or grasp the frame pad when mounting or dismounting the trampoline. To dismount, jumpers should walk to the side of the mat, bend over and place their hands on the frame, then step from the mat to the ground. Users should always place their hands on the frame while mounting or dismounting.
- > Do NOT use the trampoline as a springboard to jump onto other objects.
- Remove all objects not designed for use with the trampoline from the trampoline before use. Do not let children take toys or other items onto the trampoline



- > Use trampoline only with mature, knowledgeable adult supervision.
- Do not attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat.
- Do not allow more than one person on the trampoline. Use by more than one person at the same time increases the chance of injury.



Carefully read these warnings before using this product. Failure to follow these safety instructions can result in serious injury or death.

# **WARNING**

- Do not jump or step onto the frame pad as it was not designed to support the weight of a person.
- Do not use the trampoline while holding or wearing any type of sharp or pointed objects such as jewelry, watches, rings, eyewear and necklaces before using this product. Do not wear loose fitting clothing that may catch or snag during play.
- > Never wear footwear (e.g. shoes) when using the trampoline.
- FRAME PADS Frame pads are there to protect user from any fall or landing on the springs and frame. On no account should people be permitted to sit or stand on them when the trampoline is in use. You should also make sure that smaller users do not use the inside edges of the pads as a "handle" when getting up on to the trampoline.
- Never use the trampoline without the frame pad being securely attached. Properly tie down the frame pad before each use. Improper assembly of the frame pad may lead to injury!
- Always check to ensure there are no obstructions or objects under the trampoline. Also check that there are no pets or other people under the trampoline.
- Do not jump on the trampoline with a snowboard, skateboard, roller blades, bicycle or any other equipment. DO NOT hold any foreign objects not authorized by the manufacturer in your hand and DO NOT place any objects on the trampoline while anyone is jumping on it. Please be aware of your surroundings to ensure there are no objects that could cause harm when you are playing on the trampoline.
- The frame of your trampoline is made of steel and it will conduct electricity. No electrical equipment (lights, heaters, extension cords, household appliances, etc.) should be permitted in or on the enclosure under any circumstances to avoid the risk of electrocution.

### Trampoline Parts List

### \* Preassembled


Key Number	Part Picture	Description	Quantity
1		Trampoline Mat *	1
2	* * * * * * * * * * * * * * * * * * *	Frame Pad *	1
3	$\bigcirc$	Top Rail with Rubber Caps *	1
4		Spring-16N *	30
5		Leg Post with Cap	4
6		Leg Post	2
7	Ø	Grey Cap	2
8		Handrail Support	2
9		Handlebar	1
10	9	Rubber caps *	6
S1		Screw Set	4
S2	$\sum$	Wrench	1

### Assembly

### STEP 1: Attach Legs with Caps to the Trampoline


Place the trampoline face down on a flat and protected surface. Remove all rubber caps and tightly screw the four Leg Posts with Caps (#5) onto the threaded sockets as shown.

Note: The two empty sockets will be used to connect the handlebar in the next step and must be located in front of the Trampoline logo as shown in the bottom right picture.




### STEP 2: Attach Leg Posts to the Trampoline

Screw Leg Posts (#6) tightly into the two threaded sockets as shown. Make sure these are positioned in front of the logo.









### STEP 3: Assemble Handle Supports - Two Adult needed for this step

- Lift the trampoline and insert the two front Leg Posts (#6) into the brackets on the Handrail Supports (#8).
- Attach the Handlebar (#9) to the two Handrail Supports (#8) as shown. Make sure the click button is locked securely in place.






### STEP4: Attach Handlebar

- Install Screw Set (#S1) to the bracket to securely hold tubes #6 and #8 together. Tighten with the wrench provided.
- > Place Grey Cap (#7) onto the leg posts when finished.

Note: Make sure the Jump Mat Logo is parallel to the handlebar.



### **Completed product**

The trampoline should look as shown below when completed. Inspect the entire trampoline and make sure all parts are properly secured before allowing children to use. Constant adult supervision is required.



### Care and Maintenance



Failure to follow these instructions to ensure proper operational condition of your trampoline may lead to serious injury or death.

# 

- The trampoline must be inspected prior to every use. The legs should be locked securely into place. If any part becomes damaged or worn, please stop using the trampoline immediately until this part is replaced with authorized parts.
- If you see any signs of stretched or damaged springs, do not use the trampoline until replacement springs are properly installed. Please contact our customer service representatives to order original replacement parts.
- Please do not use unauthorized parts to assemble the trampoline. This may damage the integrity of the product and can cause injuries during use.
- Inspect the trampoline before each use and replace any worn, defective or missing parts. The following conditions could represent potential hazards:
  - Deterioration in the stitching or fabric of the mat or frame padding
  - Bent or broken support system(frame)
  - Sharp protrusions on the support (frame) or suspension system

### **Product Warranty**

Dyaco Canada Inc. warrants this unit, to the original purchaser, to be free from defects in material and workmanship for the period of time listed below. Warranty time begins at the time of purchase. Normal wear and user's abuse are not covered in the warranty. Weather damage and other such acts of nature are not covered by the Manufacturer's warranty. Commercial use and/or transfer of ownership voids the warranty.

### Trampoline

Frame	1 Year
Mat	1 Year
Springs	90 days
Frame Pad	90 days

For warranty service contact our Customer Service Dept.: 1-888-707-1880 (toll free), Monday-Friday 8:30 A.M. to 5:00 P.M. Eastern Standard Time

### LIABILITY

While every attempt is made to embody the highest degree of safety in all equipment we cannot, however, guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, that no representative of the Company can waive or change. This equipment is intended for residential use only. This equipment is not to be used in places of public assembly such as schools, nurseries, day care centre, churches and parks. Dyaco Canada Inc. cannot assume any liability for such use. Any commercial, institutional or public use of this equipment will void the warranty.

PLEASE NOTE: ANY REPAIRS OR REPLACEMENTS MUST BE MADE USING AUTHORIZED ORIGINAL MANUFACTURER PARTS IN ORDER FOR THIS WARRANTY TO BE VALID.

DO NOT RETURN PRODUCT TO THE STORE. PLEASE CONTACT OUR CUSTOMER SERVICE FOR PARTS OR ASSEMBLY INSTRUCTIONS. STORES ARE NOT EQUIPPED TO PROVIDE CUSTOMER SERVICE FOR THIS PRODUCT.

> For Customer Service, please call 1-888-707-1880 or customerservice@dyaco.ca Monday – Friday 8:30 AM – 5:00 PM Eastern Time

> > Dyaco Canada Inc.

### 5955 Don Murie Street Niagara Falls, Ontario L2G 0A9



Please visit us online for information about our other brands and products manufactured and distributed by Dyaco Canada Inc.



spiritfitness.ca



xterrafitness.ca



dyaco.ca/UFC/UFC-home.html



solefitness.ca

dyaco.ca/products/everlast.html

spiritfitness.ca/johnnyg.html



For more information, please contact Dyaco Canada Inc. T: 1-888-707-1880 | 5955 Don Murie St., Niagara Falls, Ontario L2G 0A9 | <u>sales@dyaco.ca</u>

Dyaco Canada Inc. dyaco.ca